



WILAPLAT Accessories

Fibre Tip Masking Pen, red or blue

Description

The excellent covering efficiency of the Red Masking Pen makes it ideally suited for accurate, partial stopping off when handling rhodium. The blue pen is especially suited for applications using silver baths.

Application

We recommend degreasing the work pieces before masking, either electrolytically or simply with alcohol. The dry, grease-free surfaces can now be masked. After allowing to dry for about 3 minutes, electro-plating can begin immediately.

When the coating process is finished, the red masking can be removed either with alcohol or acetone and the blue with acetone.

Warning!

Chemicals and materials used in electro-plating techniques can be corrosive or poisonous. During use, storage, transportation and disposal the relevant guidelines must be observed.

For further information see the ECC Safety Data Sheets